

---

# ANYLOAD®

## OCSD-P380 WIRELESS DYNAMOMETER

### USER MANUAL



## TABLE OF CONTENTS

|  |           |
|--|-----------|
| <b>SAFE OPERATION GUIDE .....</b>                          | <b>2</b>  |
| <b>CHAPTER 1 FEATURES AND SPECIFICATION .....</b>          | <b>3</b>  |
| 1. Features .....  | 3         |
| 2. Main technical data .....                               | 3         |
| 3. Specifications .....                                    | 4         |
| 4. Appearance illustration .....                           | 4         |
| 5. Power supply .....                                      | 5         |
| <b>CHAPTER 2 DISPLAY AND KEYS .....</b>                    | <b>6</b>  |
| 1. LCD display .....                                       | 6         |
| 2. Keys .....  | 6         |
| <b>CHAPTER 3 WIRELESS INDICATOR OPERATION GUIDE .....</b>  | <b>7</b>  |
| <b>CHAPTER 4 DYMOMETER FUNCTION GUIDE .....</b>            | <b>8</b>  |
| 1. On/off .....  | 8         |
| 2. Zero .....  | 9         |
| 3. Tare .....  | 9         |
| 4. Peak Hold .....   | 9         |
| 5. Accumulation .....                                      | 9         |
| 6. Accumulation Search .....                               | 9         |
| 7. Accumulation Clear .....                                | 10        |
| 8. Battery Voltage .....                                   | 10        |
| 9. Unit .....  | 10        |
| 10. Return .....   | 10        |
| 11. Set point .....  | 11        |
| <b>CHAPTER 5 PARAMETER SETTING &amp; CALIBRATION .....</b> | <b>12</b> |
| 1. Key function .....                                      | 12        |
| 2. Parameter setting .....                                 | 12        |
| 3. Calibration .....                                       | 14        |
| <b>CHAPTER 6 SIGNAL ILLUSTRATION .....</b>                 | <b>15</b> |
| <b>CHAPTER 7 TROUBLESHOOTING GUIDE .....</b>               | <b>16</b> |
| <b>CHAPTER 8 RS232 PROTOCOL .....</b>                      | <b>17</b> |

## SAFE OPERATION GUIDE :

1. Do not make lifts beyond rated load capacity of the dynamometer and the shackle(s).
2. Do not perform overhead weighing. Stay clear when Dynamometer is in operation.
3. Do not perform weighing under strong wind as it may cause incorrect readings.
4. Do not perform weighing in an environment with rapid temperature changes as it may cause incorrect readings.
5. Do not attempt to open the Dynamometer, there are no serviceable parts inside.
6. Do not remove wire rope stopper from hook. For safety reasons, always apply.
7. Remove all loads from shackle or hook when not in use.
8. Before weighing, check that all hanging, load- receiving elements and devices are in good condition.
9. Check hook, shackle, safety pins, and latches periodically. Contact your dealer for replacement parts in case of defect, deformities or wearing.
10. Always lift loads vertically.

## CHAPTER 1 FEATURES AND SPECIFICATIONS

### Introduction:

OCSD Wireless Dynamometer is a well-built industry use instrument for different applications, and is microprocessor controlled for precision accuracy. Parameter settings and calibration are easy to operate through the wireless indicator or by the keys on the Dynamometer.

### 1. Features

- Rugged construction, aluminum and alloy steel capacities are powder coated.
- Accuracy: 0.05% for 1-50t, 0.1% for above 50t capacity.
- Dual direction wireless communication
- All functions and units are clearly display on the LCD (with backlighting)
- Digits are 1 inch high for easy distant viewing.
- Two user programmable Set-Point can be used for safety and warning applications.
- The dynamometer is powered by 3 standard AA size alkaline batteries.
- All commonly used internationally recognized units are available: Kilograms (kg), Short Tons (t), Pounds (lb), Newton (N) and kilo-Newton (kN).
- Operation through wireless handheld indicator, easier to calibrate (with password)
- 4 local mechanical keys: "ON/OFF", "ZERO", "PEAK" and "Unit Change".
- Low battery warning.
- RF wireless handheld indicator is powered by 4 standard AA size alkaline batteries.


### 2. Main technical data

|                     |   |
|---------------------|---|
| Display             | 25mm (1") 5 digits LCD with backlight       |
| Power on zero range | 20% F.S.                                    |
| Manual Zero Range   | 4% F.S.                                     |
| Tare Range          | 100% F.S.                                   |
| Stable Time         | ≤5 seconds                                  |
| Overload Indication | 100% F.S. + 9e                              |
| Max. Safety Load    | 125% F.S.                                   |
| Ultimate Load       | 400% F.S.                                   |
| Dynamometer battery | AA size alkaline batteries. 1.5Vx3          |
| Indicator battery   | AA size alkaline batteries. 1.5Vx4          |
| Operating Temp.     | - 10 °C ~ + 40°C                            |
| Operating Humidity  | ≤85% RH under 20°C                          |
| Wireless Distance   | Min. 80m (default) , 200m (optional)        |
| Wireless Frequency  | 2.4GHz (default), 433MHz, 860MHz (optional) |

### 3. Specifications

| Model     | Capacity(kg) | Min. Weigh(kg) | Division(kg) | Total counts (n) |
|-----------|--------------|----------------|--------------|------------------|
| OCSD-1t   | 1000         | 10             | 0.5          | 2000             |
| OCSD-2t   | 2000         | 20             | 1            | 2000             |
| OCSD-3t   | 3000         | 20             | 1            | 3000             |
| OCSD-5t   | 5000         | 40             | 2            | 2500             |
| OCSD-10t  | 10000        | 100            | 5            | 2000             |
| OCSD-20t  | 20000        | 200            | 10           | 2000             |
| OCSD-30t  | 30000        | 200            | 10           | 3000             |
| OCSD-50t  | 50000        | 400            | 20           | 2500             |
| OCSD-100t | 100000       | 1000           | 50           | 2000             |
| OCSD-200t | 200000       | 2000           | 100          | 2000             |

### 4. Appearance illustration



Cap: 1-5t

Cap: 10-200t

#### DIMENSIONS (Dimensions shown are nominal and subject to tolerances)

| MODEL     | CAP  | A(mm) | B(mm) | C(mm) | D(mm) | φ(mm) | H(mm) | Material    |
|-----------|------|-------|-------|-------|-------|-------|-------|-------------|
| OCSD-1t   | 1t   | 245   | 112   | 37    | 190   | 43    | 335   | Aluminum    |
| OCSD-2t   | 2t   | 260   | 123   | 37    | 195   | 51    | 365   | Aluminum    |
| OCSD-3t   | 3t   | 260   | 123   | 37    | 195   | 51    | 365   | Aluminum    |
| OCSD-5t   | 5t   | 285   | 123   | 57    | 210   | 58    | 405   | Aluminum    |
| OCSD-10t  | 10t  | 320   | 120   | 57    | 230   | 92    | 535   | Alloy Steel |
| OCSD-20t  | 20t  | 375   | 128   | 74    | 260   | 127   | 660   | Alloy Steel |
| OCSD-30t  | 30t  | 420   | 138   | 82    | 280   | 146   | 740   | Alloy Steel |
| OCSD-50t  | 50t  | 465   | 150   | 104   | 305   | 184   | 930   | Alloy Steel |
| OCSD-100t | 100t | 570   | 190   | 132   | 366   | 229   | 1230  | Alloy Steel |
| OCSD-200t | 200t | 720   | 265   | 183   | 440   | 280   | 1362  | Alloy Steel |

**WEIGHTS**

|                                  |                 |                 |                 |                  |                  |
|----------------------------------|-----------------|-----------------|-----------------|------------------|------------------|
| <b>Model</b>                     | <b>OCSD-1t</b>  | <b>OCSD-2t</b>  | <b>OCSD-3t</b>  | <b>OCSD-5t</b>   | <b>OCSD-10t</b>  |
| <b>Unit Weight (kg)</b>          | 1.6             | 2.1             | 2.1             | 2.7              | 10.4             |
| <b>Weight with shackles (kg)</b> | 3.1             | 4.6             | 4.6             | 6.3              | 24.8             |
| <b>Model</b>                     | <b>OCSD-20t</b> | <b>OCSD-30t</b> | <b>OCSD-50t</b> | <b>OCSD-100t</b> | <b>OCSD-200t</b> |
| <b>Unit Weight (kg)</b>          | 17.8            | 25              | 39              | 81               | 210              |
| <b>Weight with shackles (kg)</b> | 48.6            | 73              | 128             | 321              | 776              |

**5. Power supply**

Dynamometer battery: AA size alkaline batteries. 1.5VX3

Indicator battery: AA size alkaline batteries. 1.5VX4






Current: the dynamometer average current is about DC 35mA, 3pcs new batteries can be used for about 40hours under continuous working.

Wireless indicator average current is about DC 28mA, 4pcs new batteries can be used for about 80hours under continuous working.

Low battery warning: When the digits are flashing, it means the battery needs to be replaced. The Dynamometer or wireless indicator will power off automatically after one hour without operation.

## CHAPTER 2 DISPLAY AND KEYS

### 1. LCD Display

- a) 25mm (1") Height 5 digits LCD display.
- b) : Appear when wireless signal is stable; disappear when no signal; flashing when signal is weak.
- c) : Battery Voltage, : Full, : Low, : Empty
- d) **PEAK**: Current value is Peak Hold value (maximum value).
- e) **MEM**: Appears once when Parameter or Calibration value is stored. Long time appearance means current value is Accumulation data.
- f) **STB**: Stable Status.
- g) **KN**: "kilo-Newton", **N**: "Newton". Tare status "N" will flash.
- h) **t** : "Ton"
- i) **lb** : "Pound"
- j) **kg** : "Kilogram "

### 2. Keys

- a) **ON/OFF key**
  - I. Press "**ON/OFF**" Key for 1 second, the Dynamometer will turn on.
  - II. In ON status, Press "**ON/OFF**" Key for 1 second, the Dynamometer will turn off.
- b) **ZERO key**

When Dynamometer is switched on with no load, but there are small digits on the screen, press this key to obtain the zero reading.
- c) **UNIT key**

Press UNIT key, the unit on LCD will display in loop as follows: "kg"→"lb"→"N"→"kN"→"t"→"kg".
- d) **PEAK key**

When load is changing, press this key and it will catch and display the maximum reading of the load.

Press this key again, reading will return to normal.

## CHAPTER 3 WIRELESS INDICATOR OPERATION GUIDE

a) **【ON/OFF】**

- I. Press “**ON/OFF**” Key for 1 Second, the indicator will turn on.
- II. In ON status, Press “**ON/OFF**” Key for 1 Second, the indicator turns off.

b) **【ZERO】**

- I. In testing status, there are small digits on screen, press this key to obtain the zero reading.
- II. In Parameter Setting status, it is used as a scrolling up digit.

c) **【TARE】**

- I. When there is tare weight such as a container, after the reading is stable, press this key, it will display “0”, and “**N**” indicator will flash.
- II. Put the object(s) into the container, the dynamometer will display the net weight.
- III. If the object(s) and container are moved, the dynamometer will display a minus value.
- IV. During Parameter Setting, it can also be used as a directional key.

Used as function shift, or can be combined with other key.

- Press **【MODE】** key once, it will display “OFF”, press **【ENTER】** Key, it will wirelessly turn off dynamometer, and indicator will display “noSIG”, means no signal.
- Press **【MODE】** key twice, it will display “SETUP”, Press **【ENTER】** Key access Parameter Setting. After parameter setting is finished, press **【MODE】** key to confirm setting to return to test mode.
- Press **【MODE】** key 3 times, display will read “dC”, Press **【ENTER】** Key to read current battery voltage, press **【MODE】** key again to return to test mode.
- Press **【MODE】** key 4 times, it display “Unit”, Press **【ENTER】** Key to access unit selection. Press **【ZERO】** key to select unit, press **【MODE】** key again to return to test mode.
- Press **【MODE】** key 5 times, display will read “ACCU”, Press **【ENTER】** Key to access Accumulation status, press **【MODE】** key to return to test mode.
- Press **【MODE】** key 6 times, display will read “SACCU”, Press **【ENTER】** Key to access Accumulation Search status, press **【MODE】** key to return to test mode.
- Press **【MODE】** key 7 times, display will read “CLEAR”, Press **【ENTER】** Key to access Accumulation clear status, display will read “CLr 1”, Press **【TARE】** Key, display will read “noCLr”. Press **【MODE】** key key to return to test mode.
- Press **【MODE】** key 8 times, display will read “CLlbr”, Press **【ENTER】** Key to enter into calibration program, after calibration is finished, press **【MENU】** key to return to test MENU. Details on Pg.13
- Press **【MODE】** key 9 times, display will read “ESC”, Press **【ENTER】** Key to return to test mode.

e) **【ENTER】**

Used as function selection, normally combined with **【MODE】** Key

f) **【PEAK】**

When load is changing, press this key to catch and display the maximum reading of the load.

## CHAPTER 4 DYNAMOMETER FUNCTION GUIDE

**Note:** ( ) means the key on the dynamometer

【 】 means the key on the indicator

〔 〕 means the display content

### 1. ON/OFF

#### ▪ TURN ON dynamometer

| OPERATION | DISPLAY  | ILLUSTRATION                            |
|-----------|----------|---|
| (ON/OFF)  | 〔88888〕  | Display twice, self test                |
|           | 〔 Ert 〕  | Display twice                           |
|           | 〔u=3.72〕 | Display current software version        |
|           | 〔CH=E3〕  | Display current wireless channel E3     |
|           | 〔 5000〕  | Display capacity, e.g. 5t               |
|           | 〔U=3.98〕 | Display current battery voltage is 3.98 |
|           | 〔——〕     | Waiting stable                          |
|           | 〔 0〕     | Displays current load, generally is 0   |

#### ▪ TURN ON indicator

| OPERATION | DISPLAY         | ILLUSTRATION   |
|-----------|-----------------|--|
| 【ON/OFF】  | 〔88888〕         | Display twice, self test   |
|           | 〔 Ert 〕         | Display twice  |
|           | 〔u 1.2〕         | Display current software version   |
|           | 〔CH=E3〕         | Display current wireless channel E3  |
|           | 〔U=3.98〕        | Display current battery voltage is 3.98  |
|           | 〔——〕            | Waiting stable   |
|           | 〔 0〕 or 〔noSIG〕 | If display 0, means the indicator can communicate with the dynamometer, if display noSIG, means no signal from dynamometer |

#### ▪ TURN OFF dynamometer

|   |                  |  |
|---|------------------|--|
| 1 | Manual Power OFF | Press (ON/OFF) Key for 1 second  |
| 2 | Remote Power OFF | Press 【MODE】 Key to select "OFF", press 【ENTER】 Key  |
| 3 | Auto Power OFF   | Choose turn off method in parameter setting, the dynamometer will display 〔 - 〕 if having no operation after 15 minutes to save power, and it will turn off automatically after 60minutes. |

▪ TURN OFF indicator

|   |                  |   |
|---|------------------|---|
| 1 | Manual Power OFF | Press <b>【ON/OFF】</b> Key for 1 second                                    |
| 2 | Auto Power OFF   | The indicator will turn off automatically after 3 minutes if not operated |

## 2. ZERO

|   | OPERATION           | DISPLAY | When Dynamometer turns on, generally it displays [ 0 ]. In case no weight on the Dynamometer but display other than '0', press this button to reset it. |
|---|---------------------|---------|---|
| 1 | Press ( ZERO )      | [ 0 ]   |   |
| 2 | Press <b>【ZERO】</b> |         |   |

## 3. TARE

| OPERATION           | DISPLAY | After turned on the Dynamometer, hang the tare weight, such as sling cable, then press this key, "TARE" light will turn on. The scale will display net weight of the goods. |
|---------------------|---------|---|
| Press <b>【TARE】</b> | [ 0 ]   |   |

## 4. PEAK HOLD

| OPERATION    | ILLUSTRATION                                     |
|--------------|--|
| Press (PEAK) | Catch and display Maximum value of changing load |
| Press (PEAK) | reading return to normal                         |

## 5. ACCUMULATION

| OPERATION                       | DISPLAY   | ILLUSTRATION                     |
|---------------------------------|-----------|----------------------------------|
| Press <b>【MODE】</b> key 5 times | [ ACCU ]  |                                  |
| Press <b>【ENTER】</b>            | [ No*** ] | Current accumulation time        |
|                                 | [ H**** ] | Front four digits of total value |
|                                 | [ L**** ] | Rear four digits of total value  |

After display above contents twice, the dynamometer will return automatically.

## 6. ACCUMULATION SEARCH

| OPERATION                       | DISPLAY   | ILLUSTRATION                     |
|---------------------------------|-----------|----------------------------------|
| Press <b>【MODE】</b> key 6 times | [ SACCU ] |                                  |
| Press <b>【ENTER】</b>            | [ No*** ] | Current accumulation time        |
|                                 | [ ***** ] | Current weight reading           |
|                                 | [ H**** ] | Front four digits of total value |
|                                 | [ L**** ] | Rear four digits of total value  |
| Press <b>【MODE】</b> key again   |           | Return                           |

Press **【TARE】** and **【ZERO】** can check different times, weight and accumulation.

## 7. ACCUMULATION CLEAR

| OPERATION                       | DISPLAY   | ILLUSTRATION                           |
|---------------------------------|-----------|--|
| Press <b>【MODE】</b> key 7 times | [[CLEAR]] |  |
| Press <b>【ENTER】</b>            | [[CLr 1]] | Ask if you want to clear or not        |
|                                 | [[noCLr]] | Press <b>【MODE】</b> key Cancel clear   |
|                                 | [[88888]] | Press <b>【ENTER】</b> key Confirm clear |

## 8. BATTERY VOLTAGE

| OPERATION                        | DISPLAY   | ILLUSTRATION                     |
|----------------------------------|-----------|----------------------------------|
| Press <b>【MODE】</b> key 3 times, | [[U *.*]] | Displays current battery voltage |
| Press <b>【MODE】</b> key again    |           | Return                           |

Note : Battery voltage normally between [[U 3.50]] to [[U 4.70]] , if below [[U 3.10]] , the display will flash, Battery should be replaced.

## 9. UNIT

|   | OPERATION                       | DISPLAY   | ILLUSTRATION   |
|---|---------------------------------|-----------|--|
| 1 | Press <b>【MODE】</b> key 4 times | [[UnIt ]] |  |
|   | Press <b>【ENTER】</b> key        | [[Un=0]]  | Un=0, the unit is kg, press <b>【ZERO】</b> to select unit from 0-4, 1 means lb, 2 means N, 3 means KN, 4 means ton. |
|   | Press <b>【MODE】</b> key         | [[ 0]]    | Confirm unit chosen and return   |
| 2 | Press (UNIT)                    | [[Un =0]] | The dynamometer will display kg, lb, N, kN, ton in loop.   |

## 10. RETURN

| OPERATION                       | DISPLAY  | ILLUSTRATION                    |
|---------------------------------|----------|---------------------------------|
| Press <b>【MODE】</b> key 9 times | [[ ESC]] |                                 |
| Press <b>【ENTER】</b> key        | [[ 0]]   | Return to normal testing status |

## 11. SET POINT

There are two user programmable Set-Point can be used for safety and warning applications or for limit weighing.

—      1 LO SP1 1 HI      2 LO SP2 2 HI

| OPERATION   | DISPLAY             | ILLUSTRATION   |
|---|---------------------|--|
| Press <b>【MODE】</b> key twice                         | 〔SETUP〕             | Confirm, enter into parameter setting  |
| Press <b>【ENTER】</b>                                  | 〔SP1 〕              | Set point 1  |
| Press <b>【ENTER】</b> to confirm                       | 〔1 OFF〕             | New dynamometer, it displays 1 OFF, if parameter set, it display set value.  |
| Press <b>【ZERO】</b> to choose                         | 〔1 HI〕 or<br>〔1 LO〕 | There are 3 choices, 1 OFF means you do not set point, 1 HI means the indicator will alarm when load exceeds the value you set, 1 LO means the indicator will alarm when load is smaller |
| Press <b>【ENTER】</b> to confirm                       | 〔02000〕             | The screen will display 02000, if parameter is changed, the screen display set value.  |
| Press <b>【ZERO】</b> and <b>【TARE】</b> to change value | 〔01000〕             | Set “1 HI” or “1 LO” Value. e.g. 1000kg  |
| Press <b>【ENTER】</b> to confirm                       | 〔 SP2〕              | Set point 2  |
| Press <b>【ENTER】</b> to confirm                       | 〔2 OFF〕             | The screen will display 2 OFF, if parameter changed, it will display set   |
| Press <b>【ZERO】</b> to choose                         | 〔2 HI〕 or<br>〔2 LO〕 | There are 3 choices, 2 OFF means you do not set point, 2 HI means the indicator will alarm when load exceeds the value you set, 2 LO means the indicator will alarm when load is smaller |
| Press <b>【ENTER】</b> to confirm                       | 〔01200〕             | The screen will display 01200, if parameter is changed, the screen display set value.  |
| Press <b>【ZERO】</b> and <b>【TARE】</b> to change value | 〔03000〕             | Set “2 LO” or “2 HI” Value. e.g.3000kg   |

If you do not need to set an item, you only need to press **【ENTER】** until it displays next function.

## CHAPTER 5 PARAMETER SETTING & CALIBRATION

Parameter setting and calibration will be operated through wireless indicator

### 1. Key function

| KEY            | FUNCTION       |
|----------------|----------------|
| <b>【TARE】</b>  | Move digit     |
| <b>【ZERO】</b>  | Set value up   |
| <b>【MODE】</b>  | Store and exit |
| <b>【ENTER】</b> | Confirm        |

### 2. Parameter setting

| ACTION                          | DISPLAY | DESCRIPTION  |
|---------------------------------|---------|--|
| Press <b>【MODE】</b> key twice   | 〔SETUP〕 | Enter parameter setting program.   |
| Press <b>【ENTER】</b>            | 〔FS=0X〕 | The screen will display the calibrated capacity. If required, press <b>【ZERO】</b> to change the capacity from 02/03/05/06/10/15/20/30/50/60/75/80t circularly.   |
| Press <b>【ENTER】</b> to confirm | 〔Id=0X〕 | The screen will display the calibrated division. If required, press <b>【ZERO】</b> to change the division from 01/02/05/10/20 circularly. Refer table below.  |
| Press <b>【ENTER】</b> to confirm | 〔Pt=X〕  | The screen will display the calibrated decimal points. If required, press <b>【ZERO】</b> to change the decimal points from 0=xxxxx, 1=xxxx.x, 2=xxx.xx, 3=xx.xxx circularly. Refer table below.   |
| Press <b>【ENTER】</b> to confirm | 〔Ab=XY〕 | This is for display zero range. A: zero range set manually; b: zero range set automatically. There are 6 options for both A and b: 0=0%FS; 1=2%FS; 2=4%FS; 3=10%FS; 4=20%FS; 5=50%FS. Recommended (default) setting is Ab=24 (A=2, b=4).                 |
| Press <b>【ENTER】</b> to confirm | 〔Cd=XY〕 | C: zero tracking range. There are 6 options: 0=0d; 1=0.5d; 2=1d; 3=1.5d; 4=2d; 5=2.5d; d: display speed. There are 3 options: 0=slow; 1=average; 2=fast. Before calibration, set Cd=00 to achieve high accuracy, after calibration, set Cd=12 (default). |
| Press <b>【ENTER】</b> to confirm | 〔LL=X〕  | This is for filter parameter. There are 6 options, from smallest to biggest. Before calibration, set LL=0; after calibration, set LL=1 (default)   |
| Press <b>【ENTER】</b> to confirm | 〔Un=X〕  | The screen will display the calibrated unit. If required, press <b>【ZERO】</b> to change the unit from 0=kg, 1=lb, 2=N, 3=KN, 4=t circularly.   |

|                                    |          |   |
|------------------------------------|----------|---|
| Press <b>【ENTER】</b><br>to confirm | 〔OFF X〕  | This is for turn off method. There are 3 options: 0: turn off by hand; 1: if no operation, the screen will display “----” after 15 minutes to save power; 2: if no operation, the screen will display “----” after 15 minutes, and turn off automatically after 60 minutes (default).                   |
| Press <b>【ENTER】</b><br>to confirm | 〔SP1 〕   | Set point 1   |
| Press <b>【ENTER】</b><br>to enter   | 〔1 OFF〕  | The screen will display the calibrated function of Set Point 1. If required, press <b>【ZERO】</b> to change the function. There are 3 options: 1 OFF: turns off Set Point 1; 1 HI: the alarm will on when the load exceeds the set value; 1 LO: the alarm will on when the load not reach the set value. |
| Press <b>【ENTER】</b><br>to confirm | 〔XXXXX〕  | Press <b>【ZERO】</b> and <b>【TARE】</b> to change the set value of Set Point 1. If selected 1 OFF for Set Point 1, no need to change anything.  |
| Press <b>【ENTER】</b><br>to confirm | 〔SP2 〕   | Set point 2   |
| Press <b>【ENTER】</b><br>to enter   | 〔2 OFF〕  | The screen will display the calibrated function of Set Point 2. If required, press <b>【ZERO】</b> to change the function. There are 3 options: 2 OFF: turns off Set Point 2; 2 HI: the alarm will on when the load exceeds the set value; 2 LO: the alarm will on when the load not reach the set value. |
| Press <b>【ENTER】</b><br>to confirm | 〔XXXXX〕  | Press <b>【ZERO】</b> and <b>【TARE】</b> to change the set value of Set Point 2. If selected 2 OFF for Set Point 2, no need to change anything.  |
| Press <b>【ENTER】</b><br>to confirm | 〔g= 〕    | Acceleration of gravity   |
| Press <b>【ENTER】</b><br>to enter   | 〔9.XXXX〕 | The screen will display the calibrated gravity value (default is 9.7930). If required, press <b>【ZERO】</b> and <b>【TARE】</b> to change the gravity value according to local area gravity value. The value range is from 9.783 to 9.832.   |
| Press <b>【ENTER】</b><br>to confirm | 〔FS=0X〕  | Back to top of the parameter setting menu. Press <b>【MODE】</b> anytime to save and exit.  |

The capacity you choose is related to the division and decimal points setting, below is a detailed list:

| CAPACITY/DIVISION | FS (Full Scale) | Id (Division) | Pt (Decimal Point) |
|-------------------|-----------------|---------------|--------------------|
| 1000kg/0.5kg      | 10              | 05            | 1                  |
| 2000kg/1kg        | 02              | 01            | 0                  |
| 3000kg/1kg        | 03              | 01            | 0                  |
| 5000kg/2kg        | 05              | 02            | 0                  |
| 10000kg/5kg       | 10              | 05            | 0                  |
| 15000kg/5kg       | 15              | 05            | 0                  |
| 20000kg/10kg      | 20              | 10            | 0                  |
| 30000kg/10kg      | 30              | 10            | 0                  |
| 50000kg/20kg      | 50              | 20            | 0                  |

100t, 200t use specail software, no need to set FS,Id,Pt.

### 3. Calibration

User must set all parameter before calibration

#### One Point Calibration

| OPERATION                         | DISPLAY     | ILLUSTRATION   |
|-----------------------------------|-------------|--|
| Turn on dynamometer and indicator | [[ 0 ]]     | Make sure the dynamometer displays [[ 0 ]] before calibration. You can hang tare weight first, and then turn on the scale to get zero reading.   |
| Press <b>【MODE】</b> 8 times       | [[ CLibr ]] | Access Calibration Procedure   |
| Press <b>【ENTER】</b> to enter     | [[ CAL 1 ]] | Enter one point calibration program  |
| Press <b>【ENTER】</b> to enter     | [[ CALSP ]] | Zero point calibration   |
| Press <b>【ENTER】</b> to confirm   | [[ LoAd ]]  | Hanging test weight for calibrate  |
| Press <b>【ENTER】</b> to continue  | [[ XXXXX ]] | Will display full capacity of dynamometer which set in parameter setting, if your test weight capacity is not the same, Press <b>【ZERO】</b> and <b>【TARE】</b> to adjust the test weight value. |
| Press <b>【MODE】</b> to confirm    | [[ ----- ]] | Confirm and store the calibration value  |
|                                   | [[ -oL- ]]  |  |
|                                   | [[ End ]]   | Calibration procedure finished   |
|                                   | [[ XXXXX ]] | Shows the current weight   |

**Attention: the test weight load should be more than 20% of the full scale capacity. It is recommended to use full scale capacity load for calibration.**

## Three point calibration

If the dynamometer linearity is not good as you required, operate 3 point calibration as follows:

**Turn on the dynamometer, make sure it display [ 0 ], even with tare weight.**

When the indicator is power off, press **【MENU】** and don't release, at the same time, insert indicator into PC to get power

| OPERATION                            | DISPLAY      | ILLUSTRATION  |
|--------------------------------------|--------------|---|
| Press <b>【MENU】</b><br>,insert to PC | [[ LOCAL ]]  |   |
| Press <b>【MENU】</b><br>,insert to PC |              |   |
| Press <b>【ZERO】</b>                  | [[ CLInt ]]  |   |
| Press <b>【ENTER】</b>                 | [[ u 1.03 ]] | Display Current indicator Software version  |
|                                      | [[ 88888 ]]  | Display Twice   |
|                                      | [[ Ert ]]    | Display Twice   |
|                                      | [[ CH=E3 ]]  | Display current indicator channel E3  |
|                                      | [[ U=X.XX ]] | Display current indicator voltage is X.XX   |
|                                      | [[ SETdC ]]  |   |
| Press <b>【MENU】</b>                  | [[ SEtRF ]]  | Dynamometer RF parameter setting  |
| Press <b>【MENU】</b>                  | [[ SEt3P ]]  | Enter into 3 point calibration  |
| Press <b>【ENTER】</b>                 | [[ CAL 3 ]]  | Here take capacity 3000kg as example  |
| Press <b>【ENTER】</b>                 | [[ CALSP ]]  | Zero point calibration, wait until STB light on   |
| Press <b>【ENTER】</b>                 | [[ LoAd1 ]]  | First load calibration  |
| Hanging on first load e.g.1000kg     |              | First load must exceed 20% capacity, Waiting until STB light on.  |
| Press <b>【ENTER】</b>                 | [[ 03000 ]]  | Display capacity  |
| Press <b>【TARE】</b><br><b>【ZERO】</b> | [[ 01000 ]]  | press <b>【ZERO】</b> to adjust digit,press <b>【TARE】</b> to move digit , Input 1000, wait until STB light on |
| Press <b>【ENTER】</b>                 | [[ LoAd2 ]]  | Second load calibration   |
| Hanging on second load e.g.2000kg    |              | Second load must exceed Load 1+20% capacity, Waiting until STB light on.                                    |
| Press <b>【ENTER】</b>                 | [[ 01600 ]]  | Mention you Load2 must exceed 1600kg  |
| Press <b>【TARE】</b><br><b>【ZERO】</b> | [[ 02000 ]]  | press <b>【ZERO】</b> to adjust digit,press <b>【TARE】</b> to move digit , Input 2000, wait until STB light on |

|                                  |                               |   |
|----------------------------------|-------------------------------|---|
| Press 【ENTER】                    | 〔LoAd3〕                       | Third load calibration  |
| Hanging on third load e.g.3000kg |                               | Third load must exceed Load 2+20% capacity, Waiting until STB light on.                       |
| Press 【ENTER】                    | 〔02600〕                       | Mention you Load3 must exceed 2600kg .  |
| Press 【TARE】<br>【ZERO】           | 〔03000〕                       | press 【ZERO】 to adjust digit,press 【TARE】 to move digit , Input 3000, wait until STB light on |
| Press 【ENTER】                    | 〔-----〕<br>〔 End 〕<br>〔 3000〕 |   |
| Press 【MENU】                     | 〔SET3P〕                       |   |
| Press 【MENU】                     | 〔dFULt〕                       |   |
| Press 【MENU】                     | 〔 ESC 〕                       |   |
| Press 【ENTER】                    | 〔 3000〕                       | Calibration finish  |

**First load: LOAD1 must larger than 20% capacity, and LOAD1<LOAD2<LOAD3, at the same time, between LOAD1 and LOAD2, LOAD2 and LOAD3, the interval must bigger than 20% capacity**

## CHAPTER 6 DISPLAY ILLUSTRATION

| DISPLAY    | ILLUSTRATION                         | DESCRIPTION                                     |
|------------|--------------------------------------|---|
| 〔noSlg〕    | Without wireless signal              | Distance too far                                |
| 〔SETUP〕    | Enter into parameter setting         |   |
| 〔UAdJ 〕    | Enter voltage calibration            |   |
| 〔LoAd〕     | Calibration point                    |   |
| 〔- - - - 〕 | Exceed high limit                    | Tare weight cannot exceed full capacity         |
| 〔..... 〕   | Exceed low limit                     | Tare weight cannot be negative                  |
| 〔-----〕    | Waiting stable                       |   |
| 〔Err10〕    | Weight less than Min. Capacity       | Cannot accumulate the value                     |
| 〔Err11〕    | Accumulated times overflow           | Cannot accumulate after 30 times                |
| 〔Err12〕    | Accumulated weight overflow          | Cannot accumulate after 99999                   |
| 〔Err13〕    | Error in repeat accumulation         | Cannot accumulate one weight repeatedly         |
| 〔no***〕    | Current accumulation times           |   |
| 〔H****〕    | Front four digit of accumulated      | Total weight=front four digit + rare four digit |
| 〔L****〕    | Rare four digit of accumulated       | Total weight=front four digit + rare four digit |
| 〔 CLr 〕    | Confirm to delete accumulated weight | In case of error deletion                       |

|             |                                    |   |
|-------------|------------------------------------|---|
| [[noCLr]]   | Give up deletion                   |   |
| [[88888]]   | Confirm deletion                   |   |
| [[ --- ]]   | Input value is too large           | When you input tare or weight value                                       |
| [[ _ _ _ ]] | Input value is too small           | When you input tare or weight value                                       |
| [[noACC]]   | No accumulated value               | When you check accumulation   |
| [[ -oL0- ]] | Overload warning                   | Tare + Net weight exceed full capacity + 9e                               |
| [[ -oL1- ]] | Overload warning                   | Tare + Net weight exceed full capacity 125%                               |
| [[ -Lb- ]]  | Low battery warning                | Turns off automatically one minute later                                  |
| [[U*.**]]   | The voltage of installed batteries |   |
| [[ End ]]   | End                                | When parameter setting or calibration ready                               |
| [[ OFF ]]   | Turn off                           |   |
| [[Unstb]]   | Input value before STB light on    |   |
| [[no519]]   | No dynamometer found in range      | Turn on the dynamometer and make sure they are within the receiving range |

## CHAPTER 7 TROUBLESHOOTING GUIDE

| PROBLEM   | POSSIBLE CAUSE                                  | SOLUTION  |
|---|---|---|
| No display  | Defective batteries                             | Replace batteries                                     |
|   | Defective button                                | Require service by authorized personnel               |
|   | Power button not properly pressed               | Press and hold <b>【ON/OFF】</b> key for three seconds  |
| Digits flash  | Low battery                                     | Replace batteries                                     |
| Display does not respond to load changes                  | Faulty load cell or PCB                         | Require service by authorized personnel               |
|   | Out of calibration                              | Re- calibration                                       |
| Display experiences excessive Zero drift between weighing | Dynamometer does not stabilize after turning on | Turn on the dynamometer and leave it for 3-5 minutes. |
| Displayed weight shows large error                        | Dynamometer not zeroed before applying weight   | Press <b>【ZERO】</b> before applying weight on it      |
|   | Requires recalibration                          | Re- calibration                                       |
|   | Wrongly selected Kg or lb                       | Press <b>【UNIT】</b> key                               |
| Wireless distance shortened                               | Wireless indicator's batteries are low          | Replace batteries                                     |

## CHAPTER 8 RS232 PROTOCOL

Port : COM1  
 Baud Rate: 4800  
 Data Bits : 8  
 Stop Bits : 1  
 Parity : None

### ASCII Code and Binary hybrid transmission

| =                                    | FLAG (1Byte)                  |                                      |                               |                               |                               |   |                               |    | Unit<br>(1Byte)  | Sign and Decimal<br>(1Byte)   |
|--------------------------------------|-------------------------------|--------------------------------------|-------------------------------|-------------------------------|-------------------------------|---|-------------------------------|----|--|---|
|                                      | F1                            | F2                                   | F3                            | F4                            | F5                            | F6  | F7                            | F8 |  |   |
| p<br>r<br>e<br>a<br>m<br>b<br>l<br>e | S<br>T<br>A<br>B<br>L<br>E    | O<br>V<br>E<br>R<br>L<br>O<br>A<br>D | T<br>A<br>R<br>E              | H<br>O<br>L<br>D              | P<br>E<br>A<br>K              | B<br>E<br>T<br>T<br>E<br>R<br>Y             | S<br>P<br>A<br>C<br>E         |    | 0x30: kg<br>0x31: Lb<br>0x32: N<br>0x33: kN<br>0x34: t | (+ and -) sign:<br>High 4 bits<br>Decimal:<br>Low 4 bits                                  |
| =                                    | 0:<br>no<br>1:<br>Y<br>E<br>S | 0:<br>n<br>o<br>1:<br>Y<br>E<br>S    | 0:<br>no<br>1:<br>Y<br>E<br>S | 0:<br>no<br>1:<br>Y<br>E<br>S | 0:<br>no<br>1:<br>Y<br>E<br>S | 0:<br>L<br>O<br>W<br>1:<br>W<br>Y<br>E<br>S | 0:<br>no<br>1:<br>Y<br>E<br>S |    |  | 0:POSITIVE<br>1:NEGATIVE<br><br>0:No Decimal<br>1:1 Decimal<br>2:2 Decimal<br>3:3 Decimal |

|                                  |                 |                                  |  |
|----------------------------------|-----------------|----------------------------------|--|
| TTTTT                            | ,               | NNNNN/PPPPP                      |  |
| 5Byte                            | 1Byte           | 5Byte                            |  |
| Tare value                       | Separate symbol | Net value and Peak value         |  |
| 0x30~0x39<br>Overload:<br>3SP+OL |                 | 0x30~0x39<br>Overload:<br>3SP+OL |  |

Example:

67.8kg: (F1 F2 F3 F4 F5 F6 F7 F8 ) 30 01 30 30 36 37 38, 30 30 36 37 38

-68.1lb: (F1 F2 F3 F4 F5 F6 F7 F8 ) 31 F1 30 30 36 37 38, 30 30 36 37 38

6.78kg: (F1 F2 F3 F4 F5 F6 F7 F8 ) 30 02 30 30 36 37 38, 30 30 36 37 38