

## Upcoming Updated Products



New versions: **805BS-B-19** and **805TS-B-19A, 805TS-B-19B**

Application and function are the same.



We will be moving forward with these versions once we have depleted the -17 indicators stocks.

Important difference: Power Adaptor changes


### 805BS

<b>805BS-B-17</b>	<b>805BS-B-19</b>
	
<p>One piece. 2 pin wall adaptor, single power cord from wall socket to indicator.</p>	<p>Two pieces. 1st piece from 3 pin wall socket to adaptor, 2nd piece from adaptor to indicator.</p>
<p>Part number : <b>805BS-TRANS-17</b></p>	<p>Part Number: <b>805BS-TRANS-19</b> (comes with both pieces)</p>
<p><b>Transformers are interchangeable</b></p>	

## 805TS

<b>805TS-B-17</b>	<b>805TS-B-19A</b>
Part Number: <b>805TS-TRANS-17</b>	Part Number: <b>805TS-TRANS-19A</b> (comes with both pieces)
One piece. 2 pin wall adaptor, single power cord from wall socket to indicator.	Two pieces. 1st piece from 3 pin wall socket to adaptor, 2nd piece from adaptor to indicator.
	
<b>Transformers are interchangeable</b>	

## 805TS-B-19B – Internal Transformer

<b>805TS-B-19B</b>	Part Number: <b>805TS-TRANS-IN-19</b> (comes with both pieces; the cord and the transformer)	3 pin wall adaptor, single power cord from wall socket to indicator, since transformer is internal.	<p style="color: red; font-weight: bold; margin: 0;"><b>805TS-TRANS-IN-19</b></p> 
--------------------	--	---	--